




Register

! It is important that you need to register you scan tool (iLink series, iAuto Series and iMax Series) at first before use it.




1. Install update client iScanZilla from the disc in the package.
2. Or visit www.videnttech.com and click menu *Support & Service* to download.

2. Unzip the file and find the installer to install the update client to your computer (Windows:XP,WIN2000,WIN7,WIN8 and WIN10)



3. Take out TF card(push and eject) from scan tool, insert it to computer via card reader in correct way.

4. Fill out necessary information and click Register. Once registration is done, iScanZilla will automatically let you sign in and finish the registration of scan tool soon.




Note: Please manually register second serial no of Vident scan tool if you have more than 1 scan tool.



2. Click the desktop icon to launch the update client and click **Register**


Diagnostic Operations

- Before start diagnosis, please make sure:
 - The ignition switch is turned to ON position.
 - The engine is off.
 - The vehicle battery voltage is between 10-14 volts.
 - The scanner is correctly connected to the vehicle.
- Don't connect or disconnect the equipments while the ignition is on or the engine is running.




Update

Before updating, please make sure you have created a Vident ID and your network works correctly.




To Print Test Results



Powering up the scanner

Before using the scanner, make sure to provide power to the scanner.



Technical Support

→ Support Ticket
 iScanzilla.exe
 ✉ support@videnttech.com
 🌐 www.videnttech.com → [Home>Support>Make a Complaint](#)
 ☎ 86-0755-28305016